



3100 Leg Kit Instructions

FOR ALL 3100 SERIES EXTRACTORS MANUFACTURED IN 2009+

THE LUGS ON THE BOTTOM RING OF YOUR 3100 SERIES EXTRACTOR HAVE BEEN WELDED IN **FIXTURES PRECISELY AT 120 DEGREES.**

STEP 1

REMOVE ALL HARDWARE FROM INSERT CARRIAGE BOLT ON PACKAGE. THE BOLTS ARE EXTRACTOR LUG TO TOP LEG.



STEP 2

3 OUTER LEG THROUGH THE LEG CARRIAGE BOLTS ARE USED FOR HOOP, THEN ATTACH FLAT THE LEG TO HOOP. THE 3 HEX WASHER, AND LOCK WASHER ON USED FOR INNER LEG HOOP. HAND-TIGHTEN BOLT ON UNTIL ALL 3 LEGS ARE ATTACHED. YOU MAY NEED TO MOVE THE LEG A LITTLE TO LINE UP WITH THE EXTRACTOR LUG TO LEG HOLES.







NEXT, TAKE YOUR EXTRACTOR AND LINE LUGS UP WITH LEG

NOW TAKE YOUR 5/16 BOLTS

WITH A FLAT WASHER AND

INSERT INTO LUG TO LEG HOLE.

INSERT LOCK WASHER AND NUT

AND TIGHTEN. AFTER ALL 3 TOP

BOLTS ARE TIGHT YOU MAY THEN TIGHTEN THE CARRIAGE BOLTS.

STEP 3

SLOTS.

STEP 4

If you have any questions or concerns feel free to contact us at:

www.maxantindustries.com • sales@maxantindustries.com

978-772-0576 or 978-772-BEES (2337)

978-772-6365 (fax)

Mail: P.O. Box 454, Ayer, MA 01432 Ship: 58 Barnum Rd, Devens, MA 01434

Built to Last a Lifetime